




Hardware Install Guide ConnectCore 9C


Unpack the contents of the ConnectCore 9C and verify all the components





JTAG adapter







ConnectCore 9C development board







Documentation


Connect Raven

debugger to PC

Software CD

Connect the debugger









CAUTION!

The JTAG adapter has an orientation hole for placement on Pin one. Failure to orient adapter correctly may damage device.



Raven

Connect Raven debugger ribbon cable to JTAG adapter





Connect development board



All other trademarks are the property of their respective owners.

Connect crossover cable from PC to serial port A





Connect Ethernet cable to Ethernet connector on ConnectCore 9C module





Connect

board power

supply

WHAT'S NEXT?

The hardware installation is complete. The next step is to go to the Getting Start Guide to install the software.