


Cables

EIA-232 PC Terminal Emulator Cables, RJ-11 6-pin/4-wire to DB-9

The wiring diagram for an RJ-11 6-pin/4-wire to DB-9 PC terminal emulator cable is shown in Table 1.

Table 1: EIA-232 RJ-11 6-pin/4-wire to DB-9 PC terminal emulator cable

| From RJ-11 | Signal | Direction | Signal | To DB-9 |
|------------|--------|-----------|--------|---------|
| 4 | RxD | ← | TxD | 3 |
| 3 | TxD | → | RxD | 2 |
| 5 | SG | ↔ | SG | 5 |
| 2 | GND | ↔ | GND | Shell |



* Arrows indicate which direction the signal is flowing

NOTES:

- This cable can only be used with Software Flow Control (Xon/Xoff).
- Some Unix operating systems require carrier to be present. If this is the case, the forcedcd parameter will need to be turned on for this port at the host.